

HONDA

ES3500

GENERATOR

PROVISIONAL SERVICE INFORMATION

*Destroy this interim service information
when the permanent shop manual becomes
available.*

AMERICAN HONDA MOTOR CO., INC.
MOTORCYCLE AND POWER PRODUCTS SERVICE DEPARTMENT

CONTENTS

| | | |
|-----|--|----|
| I | SPECIFICATIONS | 2 |
| 1. | SPECIFICATIONS | 2 |
| 2. | CHARACTERISTICS | 2 |
| 3. | PERFORMANCE CURVES | 3 |
| II | PERIODIC MAINTENANCE | 4 |
| 1. | MAINTENANCE SCHEDULE | 4 |
| 2. | IGNITION TIMING ADJUSTMENT | 4 |
| 3. | TAPPET CLEARANCE ADJUSTMENT | 5 |
| 4. | CARBURETOR ADJUSTMENT | 5 |
| 5. | GOVERNOR ADJUSTMENT | 5 |
| III | TROUBLESHOOTING | 6 |
| IV | MAIN FEATURES MECHANISMS | 8 |
| 1. | GENERATING SYSTEM | 8 |
| 2. | GENERATING CIRCUIT | 9 |
| 3. | DUAL OUTPUT SYSTEM | 11 |
| 4. | FUEL CUT-OFF SOLENOID VALVE | 12 |
| 5. | AUTOMATIC CHOKE MECHANISM | 13 |
| 6. | REMOTE CONTROL KIT (OPTIONAL) | 13 |
| V | MAINTENANCE OPERATIONS | 14 |
| * | SERVICE PRECAUTIONS | 14 |
| 2. | FUEL TANK/BELT | 15 |
| 3. | ENGINE | 16 |
| 3. | CONTROL BOX | 22 |
| 4. | GENERATOR BLOCK | 28 |
| 5. | OPTIONAL PARTS | 39 |
| VI | WIRING DIAGRAM | 41 |
| VII | SUPPLEMENT (FOR AUTOMATIC CHOKE CIRCUIT) | 42 |

I-1. SPECIFICATIONS

* These specifications are subject to change without notice.

DIMENSIONS AND WEIGHTS

| | |
|----------------|-------------------|
| Overall length | 715 mm (28.2 in.) |
| Overall width | 405 mm (15.9 in.) |
| Overall height | 595 mm (23.4 in.) |
| Dry weight | 87.5 kg (193 lbs) |
| Curb weight | 99.0 kg (218 lbs) |

GENERATOR

| | |
|---------------------------|---|
| Type | Self-exciting, 2-poles, single phase, rotating field type |
| Rated output | AC: 2.8 KVA DC: 100W (12V, 8.3A) |
| Max. output | 3.5 KVA (Max. 1 hr) |
| Rated voltage | 115V/230V |
| Rated current | 24.3A/12.2A |
| Rated frequency | 60Hz |
| Voltage regulating system | A.V.R. (Automatic Voltage Regulator) system |

ENGINE

| | |
|--------------------|------------------------------------|
| Model | HONDA G80 gasoline engine |
| Type | 4 cycle, side valve, 1 cylinder |
| Total displacement | 296 cc (18.0 cu.in.) |
| Rated horsepower | 6.0 ps/3600 rpm |
| Max. horsepower | 8.0 ps/4000 rpm |
| Max. torque | 1.6 kg-m (11.6 lbs-ft)/2500 rpm |
| Compression ratio | 6.3: 1 |
| Fuel consumption | 285g/ps-h |
| Cooling system | Forced air cooling |
| Ignition system | Flywheel magneto |
| Ignition timing | 25° B.T.D.C. fixed |
| Spark plug | B-6HS, BR-6HS (NGK) |
| Carburetor | Horizontal type, butterfly valve |
| Air cleaner | Semi-dry type |
| Governor | Sentrifugal governor |
| Lubricating system | Splash type |
| Oil capacity | 1.1ℓ (2.3 U.S. pt., 1.9 Imp. pt.) |
| Starting system | Electric/Recoil Starter |
| Stopping system | Ground of primary circuit |
| Tank capacity | 14ℓ (3.7 U.S. gal., 3.1 Imp. gal.) |


I-2. CHARACTERISTICS

| | |
|--|---|
| Voltage variation rate | Momentary: 15% max. Average: 7% max. Average time: 5 minutes max. |
| Frequency variation rate | Momentary: 20% max. Average: 10% max. |
| Stability in voltage | ±1% Average time: 5 minutes max. |
| Stability in frequency | ±1% |
| Rated power factor | 0.8-1.0 |
| Insulation resistance | 10 MΩ |
| Max. load | 110% |
| Circuit breaker capacity | 31.5A/115V, 16A/230V |
| DC fuse capacity | 15A |
| Fuel consumption ratio (at rated load) | 25ℓ/h |
| Motor drive | 750W max. |


I-3. PERFORMANCE CURVES

•AC OUTPUT

AC 230V




AC 115V



•DC OUTPUT

DC 12V



★ These performances may vary in some degrees depending on the ambient temperature and humidity.


II-1. MAINTENANCE SCHEDULE

| Items | Period | Daily | Initial 20 hrs operating | Every 50 hrs operating | Every 100 hrs operating | Every 300 hrs operating or annually | Ref. page |
|---|-------------------|-------|--------------------------|------------------------|-------------------------|-------------------------------------|-----------|
| Engine Oil | Inspect Change | ○ | ○ | | ○ | | |
| Fuel Strainer | Clean | | | | ○ | | |
| Air Cleaner | Inspect Clean | ○ | | ○* | | | |
| Spark Plug | Clean Adjust | | | | ○ | | |
| Belt | Inspect Adjust | | | | ○ | | P. 15 |
| Ignition Timing | Inspect Adjust | | | | | ○ | P. 4 |
| Tappet Clearance | Inspect Adjust | | | | | ○ | P. 5 |
| Combustion Chamber (inc. VALVE lapping) | Clean | | | | | ○ | |
| Fuel Tube (Replace, if necessary) | Change | | | | | ○ | |


* Clean more frequently, if operated in dusty or sandy conditions.

II-2. IGNITION TIMING ADJUSTMENT

- (1) Remove the fan cover, starter pulley and point cover.
- (2) Rotate the flywheel in a clockwise direction until the "F" mark on the flywheel aligns with the seam between the cylinder and oil pan. At this time, the contact breaker points should just start to open. (25 B.T.D.C., FIXED)
- (3) To adjust, loosen the base plate locking screw, and move the base plate right or left. Recheck the timing to make sure that it has not changed, after tightening the locking screw.



II-3. TAPPET CLEARANCE ADJUSTMENT



Check clearance on compression stroke

- (1) Valve tappet clearance should be checked with the engine cold. Rotate the flywheel until the "T" mark on the flywheel aligns with the index mark with the piston on compression stroke.
- (2) Check the clearance of both the inlet and exhaust valves by inserting a feeler gauge between the valve stem and lifter.



Standard 0.06–0.11 mm (0.002–0.004 in.)

- (3) If the clearance is too small, adjust by grinding the stem end using an oil stone. If the clearance is excessive, discard the old valve and install a new one.

II-4. CARBURETOR ADJUSTMENT

- (1) Turn in the pilot screw until it lightly bottoms against the seat, then turn out 1-7/8 turns.
- (2) Start the engine and turn the throttle stop screw either in or out as necessary until the correct idle speed is obtained.


Specified Idle Speed: 1,400 rpm



II-5. GOVERNOR ADJUSTMENT


- (1) Rotate the governor arm all the way in a clockwise direction (the governor weights contract fully).
- (2) Make sure that the carburetor throttle is turned to the fully open position at this time.
- (3) To adjust, bend or expand the V-shaped position until the proper length of the governor rod is obtained.

- (A) Fully closed
(B) Fully open



TROUBLESHOOTING


ENGINE




TROUBLESHOOTING

GENERATOR

• AC OUTPUT




• DC OUTPUT (When the AC output is generated normally;)



GENERATING SYSTEM

The HONDA ES3500 generator employs a rotating field generating system. The rotor has a relatively weak permanent magnet with two poles, N and S, and contains the field coil (FW). The stator consists of the main coil (MW) and exciter coil (EW), wound on the laminated cores attached to the generator housing.



A.V.R. (Automatic Voltage regulator)



STATOR WINDINGS

ROTOR WINDINGS

MAGNET

GENERATING CIRCUIT

The stator's exciter coil (EW) supplies direct current to the rotor's field coil (FW) through a rectifier in the AVR and brushes contacting the rotor. As the rotating field coil's magnetic flux is cut by the stator windings, alternating current is generated in the main coil (MW) for output, and in the exciter coil (EW) for maintaining a strong rotor field.



1) Exciter Circuit


The rotor permanent magnet provides initial exciting current. As the engine starts and the rotor begins to turn, the N and S pole's magnetic flux is cut by the windings on the stator's exciter coil (EW). This induces alternating current in the exciter coil, which is then converted to direct current by a rectifier in the AVR and fed back to the rotor's field coil (FW) to strengthen the rotor's magnetic field.

2) A.C. Output Circuit and AVR (Automatic Voltage Regulator)

As direct current flows through the rotating field coil (FW), alternating current is generated in the stator main coil (MW). The induced AC output voltage is proportional to both rotor speed and field coil current.

The ES3500 generator reaches specified output voltage at 2,000 - 2,500 rpm, well below normal operating speed: 3,000 rpm (50HZ), 3,600 rpm (60HZ). Without some control, output voltage would exceed rated output at normal speed. To prevent this, the AVR controls output voltage by regulating field coil current. The AVR measures output voltage in the main coil and decreases field coil current when the output exceeds a pre-set value. Conversely, when main coil voltage drops below normal, field coil current is increased, and output voltage increases. This continuous measuring and regulating results in constant output voltage.

The A.C. output circuit has a circuit breaker to prevent current overload and subsequent damage.




3) D.C. Output Circuit

Current generated in the D.C. coil (DCW) is rectified by another rectifier and is supplied to the D.C. output terminal.


A fuse is used in the circuit for protection against current overload.

This D.C. output (12V, 8.3A) should be used only for battery charging.




DUAL OUTPUT VOLTAGE

The E3500 generator employs a dual output voltage system in which both 115V and 230V outputs are available at the same time. It accomplishes this by providing a center tap in the main coil (MW) (changing the resistance). Each circuit has its own circuit breaker and an independent output plug with a different pin lay-out preventing a miss-connection.



FUEL CUT-OFF SOLENOID VALVE



The generator incorporates a fuel cut-off solenoid valve to prevent "dieseling" when shutting off the engine. When the engine switch is turned off, in addition to an usual stopping system grounding the primary circuit, the solenoid valve is energized by the current from the generator, closing the carburetor main jet to cut off the fuel supply. Current from the D.C. coil (DCW) is rectified by a diode rectifier before entering the solenoid valve.

AUTOMATIC CHOKE MECHANISM

The ES3500 generator has an automatic choke for convenient starting, especially with the optional remote control. When the engine switch is turned to "START", the battery energizes a choke solenoid to close the choke for cold starting.

When the engine reaches 30°C (86°F) at the cylinder head, a thermoswitch turns off the solenoid to open the choke.






A manual choke is also provided for use when the battery is discharged, or when using the recoil starter.

REMOTE CONTROL KIT (OPTIONAL)

The optional remote control kit consists of a switch box, remote control cable, and relay box. The relay box is installed in the generator's control box, and is connected in parallel to the wires between the engine switch and the engine. The control cable connects the relay box to the remote switch box, which has an engine toggle switch, starter button, and pilot lamp.

DISASSEMBLY/ASSEMBLY

• INDEXES AND MARKINGS

| | |
|---|--|
|  | Refer to page |
|  | Indicates steps or points requiring special precautions or notes. |
|  | Indicates warning, there is a possibility of personal injury if instructions are not followed. |
|  | Apply oil |
|  | Apply grease |

WARNINGS

- Do not operate unit in shop unless it is well ventilated. Do not smoke or allow open flames or sparks near unit when servicing.
- To avoid personal injury, be sure to stop the engine, and make sure that engine is not high temperature whenever servicing.
- As with any source of electricity, the generator is a potential source of electric shock when misused. Exercise care to avoid shocks, especially when inspecting the unit when it is running.


| FASTENED PARTS | FASTENERS | TIGHTENING TORQUE |
|-----------------|-------------------|-------------------------------------|
| ENGINE UNIT | 10mm bolt, nut | 4.0 – 5.0 kg-m (28.9 – 36.2 lbs-ft) |
| GENERATOR UNIT | 10mm bolt, nut | 4.0 – 5.0 kg-m (28.9 – 36.2 lbs-ft) |
| DRIVEN PULLEY | 18mm nut | 6.0 – 8.0 kg-m (43.4 – 57.9 lbs-ft) |
| CYLINDER HEAD | 10mm special bolt | 3.5 – 4.0 kg-m (25.3 – 28.9 lbs-ft) |
| STANDARD TORQUE | 5mm bolt, nut | 0.4 – 0.7 kg-m (2.9 – 5.1 lbs-ft) |
| | 6mm bolt, nut | 0.8 – 1.2 kg-m (5.8 – 8.7 lbs-ft) |
| | 8mm bolt, nut | 2.0 – 2.8 kg-m (14.5 – 20.2 lbs-ft) |

- WIRE COLOR CODE (The color of wires indicated by the code below in the text are as follows:)

| | |
|------|-------------|
| B | Black |
| Bl | Blue |
| Br | Brown |
| Gr | Green |
| Gr/W | Green/White |
| Lg | Light Green |


| | |
|------|-------------------|
| Lg/B | Light Green/Black |
| Lg/R | Light Green/Red |
| Lg/W | Light Green/White |
| R | Red |
| R/B | Red/Black |
| R/W | Red/white |
| Y/B | Yellow/Black |

DRIVE BELT



• BELT TENSION ADJUSTMENT


1. Check that belt play is 3mm (1/8 in) at the middle.
2. If the belt tension is improper, loosen four generator mounting bolts, stay tightening bolt and tension lock nut. Then turn the adjusting bolt until the proper belt tension is obtained.
3. After adjusting, be sure to tighten the lock nut securely. (See tightening torque table on page 73)




ENGINE REMOVAL

* Remove these parts before you remove the engine.

1. Tank, belt cover, and belt (pg).
2. Drive pulley and generator stay.
3. Engine mounting bolts.
4. High tension cord clamp and special bolt.
5. Disconnect A connector (Engine switch/Charging coil).
6. Disconnect B connector (Starter)..
7. Disconnect C connector (Fuel cut-off/Choke solenoid).



THROTTLE KNOB



* **DISASSEMBLY:** After loosening the tightening bolt and nut, insert the tip of screw driver and expand the clearance. Then remove the control shaft.

* **LOCK NUT**
Pay attention since it is left hand thread.

* **ASSEMBLY:** Adjust length above stopper to original length.

FUEL CUT-OFF SOLENOID

WARNING


DISASSEMBLY: Before disassembling, close the fuel cock and drain gasoline in the carburetor.

CARBURETOR

* MAIN JET: #92
PILOT SCREW BACKING OFF: 1-5/8 ± 1/4 turns

SOLENOID VALVE ASSY.

* ASSEMBLY: Check the valve for proper operation.




*
Gr • Gr/W Fuel Cut-off Solenoid
Y • B Choke Solenoid
Lg • Y Thermostat Switch

b. INSPECTION


• FUEL-CUT SOLENOID

RESISTANCE VALUE: 6.7–8.7Ω


* If the specified resistance can not be obtained, replace the solenoid valve with new one.



THERMOSTAT SWITCH



INSPECTION — Thermostat Switch




* Check continuity between Lg and Y leads when the thermostat switch is in water at the specified temperature.

| WATER TEMP | CONTINUITY |
|------------------------|------------|
| Above 34° C (93° F) | YES |
| Below 18° C (64° F) | NO |


CHOKE SOLENOID

ASSEMBLY: Solenoid to carburetor cover and solenoid stay, then install on carburetor.



Adjust rod length so the manual choke rod contacts the stopper when the manual choke lever is fully closed

INSPECTION — Choke Solenoid



RESISTANCE: 7-10 Ω

CONTROL BOX

CIRCUIT BREAKER

PILOT LAMP

FREQUENCYMETER

CONTROL SWITCH

ENGINE SWITCH

DIODE
(for charging circuit)


SILICON RECTIFIER

AC RECEPTACLE


DC TERMINAL

ASSEMBLY


CONTROL BOX



• AC RECEPTACLES





CONTROL BOX



CONTROL BOX

ASSEMBLY




CONTROL BOX


•CIRCUIT BREAKER



- The main inspection herein is a continuity test. With ohmmeter, check continuity between wires shown in illustrations or photos.
- If no continuity exists, replace with new one.




•AC RECEPTACLES



- Check continuity with circuit breaker OFF and AC terminal shorted with a piece of wire as shown.

•FREQUENCYMETER



- Disconnect blue wire and measure the resistance. If out of specification, replace



RESISTANCE VALUE: 72Ω

INSPECTION

CONTROL BOX

• ENGINE SWITCH

Check continuity between the leads shown with the • mark below, setting the engine switch to "OFF", "ON", or "START".



| CODE LEADS | IG | E | BT | ST | AS | S | G | FS |
|---------------|-----|---|----|-----|----|---|---|------|
| E-SW | B/Y | B | W | B/W | Lg | Y | R | Gr/W |
| OFF | • | • | | | | | • | • |
| ON | | | • | • | • | | | |
| START | | | • | • | • | • | | |

CODE:

E ... EARTH

ST ... STARTER

G ... GENERATOR

IG ... IGNITION

BT ... BATTERY

AS ... AUTO-CHOKE SOLENOID



S ... RESTART CIRCUIT

FS ... FUEL CUT-OFF SOLENOID

• CONTROL SWITCH

Check continuity as above, setting the control switch to "ON" or "OFF".



| LEADS | R | R/W | R/B | W/Gr | W | W/B |
|-------|---|-----|-----|------|---|-----|
| C-SW | | | | | | |
| OFF | • | • | | • | • | |
| ON | | • | • | | • | • |



CONTROL BOX


● SILICON RECTIFIER

(For FUEL-CUT SOLENOID)




| POLARITY OF TESTER | | CONTINUITY |
|--------------------|-----|------------|
| (+) | (-) | |
| Gr | B/R | NO |
| B/R | Gr | YES |
| B/R | R/W | NO |
| R/W | B/R | YES |
| Gr | Br | NO |
| Br | Gr | YES |
| Br | R/W | NO |
| R/W | Br | YES |

● DIODE (FOR CHARGING CIRCUIT)



| POLARITY OF TESTER | | CONTINUITY |
|--------------------|------|------------|
| (+) | (-) | |
| Lg/R | R | NO |
| R | Lg/R | YES |

GENERATOR



ASSEMBLY

GENERATOR


•AC OUTPUT TERMINAL

WARNING

If a lead securing screw is not tightened securely, a heat may be generated.

LEAD SECURING SCREW

ASSEMBLY: Tighten securely.




•DC DIODE

INSULATING BUSHING

ASSEMBLY: Note the installing directions.

DC DIODE


W/R



ASSEMBLY


GENERATOR

•A.V.R. (Automatic Voltage Regulator)




•BRUSH HOLDER

***ASSEMBLY:** Note that brush holder is in good condition.



BRUSH HOLDER



***ASSEMBLY:**

- Install after identifying right and left parts.
- Be sure that carbon brush is above 12 mm in length and not worn unevenly.


***ASSEMBLY:** Make sure that brushes are properly fitted on slip rings.

GENERATOR

•REMOVAL GENERATOR UNIT

* After removing these parts showing below, remove the generator unit.

1. BELT COVER, BELT
2. GENERATOR STAY BOLT
3. GENERATOR TIGHTENING BOLTS and NUTS
4. TENSION BOLT and LOCK NUT
5. Disconnect the AC TERMINAL leads
6. Disconnect the 4-POLE COUPLER
7. CORD CLIP



ASSEMBLY



GENERATOR

• REAR HOUSING/DRIVEN PULLEY

DRIVEN PULLEY

- * **DISASSEMBLY:** After removing fan cover, remove pulley with fan attached.
Use a common puller commercially available, or two 8 x 60 mm bolts as pushing bolts screwing into pulley evenly.

Take care not to damage the generator.



ASSEMBLY*

GENERATOR

• ROTOR/STATOR

SLIP RINGS

- * **ASSEMBLY:** Before installing, clean away any dirt on slip ring surfaces.



ROTOR

- * **DISASSEMBLY:** After loosening off the set plate attaching bolts, lightly tap the rotor end to remove.

STATOR

- * **ASSEMBLY:** Install with wires facing up.

BALL BEARING (6304UU)

BALL BEARING (6306UU)

BEARING SET PLATE

FRONT HOUSING

- * **DISASSEMBLY:** Tap the corners of the brackets with plastic hammer off the stator.

STATOR COVER

- * **DISASSEMBLY:** Straighten the tabs to remove.

GENERATOR

b. INSPECTION


- * The main inspection in this block is resistance measuring. Read the resistance between wires shown in illustrations or pictures.
- If out of specification, replace new.

• EXCITER WINDINGS

WARNING

Use care to prevent electric shock when engine is running.

< TEST 1, 2 >



< TEST 1 >

- * Measure AC voltage between lightgreen/red and green wires with generator turning at rated rpm under no load.
- RATED RPM:**
 Type T,E,G,U 3000 rpm (50 Hz)
 Type A,S 3600 rpm (60 Hz)

AC VOLTAGE: 4-6V


< TEST 2 >

- * Measure resistance other than AC voltage measuring.

RESISTANCE VALUE : 1.5Ω

• FIELD WINDINGS

< TEST 1 >




< TEST 1 >

- * Measure DC voltage with generator turning at rated rpm.

DC VOLTAGE: 20V

- * Inspect the main windings if AC output can not be obtained at all with the rated voltage generating in the field windings. (See page 69.)
- If rated voltage is not generated, perform the next "TEST 2"
- * See the HONDA E3500 TROUBLE SHOOTING CHART (Code no. 8188000A) already issued.

< TEST 2 >



< TEST 2 >

- * Remove the brush holder and measure the resistance between slip rings.


RESISTANCE VALUE: 50Ω

INSPECTION

GENERATOR

• MAIN WINDINGS

< TEST 1 >




< TEST 1 >

* Measure resistance between AC ± (blue) and 115V (red) terminals, or AC ± and 230V (brown).

| TERMINAL | | RESISTANCE VALUE |
|----------|------|------------------|
| AC ± | 115V | 0.35 Ω |
| | 230V | 1.13 Ω |

< TEST 2 >




< TEST 2 >

* If AC output voltage is excessively high, perform this continuity test.

INSPECTION


GENERATOR

• DC WINDINGS



RESISTANCE VALUE: 0.8Ω

• DC DIODE




* Check continuity with tester + probe to heat sink and — probe to red or brown wire and recheck vice versa.

| POLARITY OF TESTER | | CONTINUITY |
|--------------------|--------------|---------------|
| (+) | (-) | |
| HEAT SINK | RED or BROWN | EXIST |
| RED or BROWN | HEAT SINK | NO CONTINUITY |


INSPECTION

GENERATOR

• A.V.R.



< TEST 1 >



* If no output is obtained or voltage is low, perform the TEST 1 and 2.

< TEST 1 >


* Check continuity with all wires in A.V.R. disconnected.

| POLARITY OF TESTER | | CONTINUITY |
|--------------------|------|---------------|
| (-) | (+) | |
| Lg/B | Lg/W | No continuity |
| Lg/W | Lg/B | Continuity |
| B | Lg/R | No continuity |
| Lg/R | B | Continuity |
| B | Gr | No continuity |
| Gr | B | Continuity |
| Lg/R | Lg/W | No continuity |
| Lg/W | Lg/R | Continuity |
| Gr | Lg/W | No continuity |
| Lg/W | Gr | Continuity |

INSPECTION

GENERATOR

< TEST 2 >




WARNING

Use care to prevent an electric shock when engine is running.

< TEST 2 >

- * After making connections of all wires in A.V.R., inspect with engine running at generator rated rpm.
- Measure output voltage while connecting between condenser Black terminal and transistor A with a suitable wire as shown.
- Replace A.V.R. as an unit if 130–140% voltage as compared to the rated voltage is measured within 2 sec. after shortcircuiting.
- Make sure to short-circuit only for 2 sec. and measure under no load. Though a spark occurs when disconnecting short-circuiting wire, no damage results in A.V.R.

< TEST 3 >




< TEST 3 >

- * Check continuity with all wires in A.V.R. disconnected.


| POLARITY OF TESTER | | CONTINUITY |
|--------------------|-----|---------------|
| (+) | (-) | |
| B | BI | No continuity |
| BI | B | Continuity |
| B | Lg | No continuity |
| Lg | B | Continuity |

OPTIONAL PARTS

• BATTERY TRAY KIT




• WHEEL KIT




OPTIONAL PARTS

• REMOCON KIT



b. INSPECTION

• SWITCH BOX



PILOT LAMP

Perform the continuity test between Gr and R/B leads.

PUSH SWITCH

Continuity test between the Lg and R leads while pushing the switch.


TOGGLE SWITCH

Continuity test between Lg and W/B leads with the switch "ON".


| Part Name | |
|-----------|-----------------------------|
| ACS | Automatic Choke Solenoid |
| AVR | Automatic Voltage Regulator |
| Bt | Battery |
| CBr | Circuit Breaker |
| CBx | Control Box |
| ChC | Charging Coil |
| CoB | Contact Breaker |
| CP~ | ~P Connector |
| DCW | DC Winding |
| EgB | Engine Block |
| ESw | Engine Switch |
| ET | Earth Terminal |
| EW | Exciter Winding |
| FCS | Fuel Cut Solenoid |
| FM | Frequency Meter |
| (F)M | Frequency Mark |
| Fu | Fuse |
| FW | Field Winding |
| GeB | Generator Block |
| IC | Ignition Coil |
| MW | Main Winding |
| OR | Output Receptacle |
| OT | Output Terminal |
| PL | Pilot Lamp |
| RCB | Remote Control Box |
| RESw | Remote Engine Switch |
| RIB | Relay Box |
| RPL | Remote Pilot Lamp |
| RSw | Remote Control Switch |
| SB | Starting Button |
| SM | Starting Motor |
| SP | Spark Plug |
| TSw | Thermostat Switch |
| ⊕M | + Mark |

Color

| | |
|----|-------------|
| B | Black |
| Bl | Blue |
| Br | Brown |
| Gr | Green |
| Lg | Light Green |
| R | Red |
| W | White |
| Y | Yellow |





MALE COUPLER (A.V.R. side)




MALE COUPLER (Diode side)


MALE COUPLER (Control box side)



SUPPLEMENT (CHANGES AFTER FIRST _____ UNITS)



b. INSPECTION



When inspecting the fuse without opening the control box, check the continuity between the Y and Lg leads with the engine switch in the "START" position.